

Article-No.: 126069

Long Active Stylus with Tether Cord Zebra XPAD/ XSLATE L10

Technical data



Highlights

- compact, precise and comfortable active pen for the Zebra L10 and B10 as well as the XC series
- incl. pin cord
- reacts to pressure sensitivity, tilt and display proximity
- requires active digitizer display
- can be easily stored in the integrated pen garage of the XPAD L10s or in the Soft Handle (410052) of the XSLATE and XBOOK L10s
- this pen is already included in the XPAD L10s with ViewAnywhere Active Display
- Note: compatible with XPAD, XSLATE and XBOOK require the slot of the Soft Handle carrying handle